


# R4816-IP MODULE FOR RUNNER

1. Connect the IP-Module to your Computers LAN port with the supplied Patch cable.
2. Connect power to the IP-Module, this can come from the Alarm Panel or even a 12V battery.



3. Before your computer can communicate with the IP-Module you may have to set the computers IP address.  
Address must be within: 192.168.1.□□□ (1 to 243) **Don't use 192.168.1.100** Recommended IP = 192.168.1.101  
Choose your version of windows you're using and follow the steps below.

### Changing your IP Address on Windows XP

192.168.1.101

Step 1

Step 2

Step 3

Step 4

Step 5

### Changing your IP Address on Windows 7

192.168.1.101

Step 1


Step 2

Step 3 (Version 4)

Step 4


Step 5

4. Open your web browser: Internet Explorer 9 & above, Safari, Fire-Fox or Google Chrome (*Explorer 6,7 & 8 not supported*)
5. In the browser type in the IP-Modules Address **192.168.1.100** then press **Enter**  
The IP-Modules Home page should come up




# NETWORK SETUP

1. From the IP-Modules Home page Click Login




2. Click in the Password box and type in the System Password **000000** then press **Enter** (000000 is the default system password)



3a. For simple Network Setup click on the Box **Enable DHCP** (a small tick will appear).

With DHCP enabled the IP-Module will automatically request the network configuration from the router. Please note that the Router will also assign the IP-Module with a new IP Address.


4. Now continue the rest of your Setup  
For CID monitoring go to page 3  
For APP monitoring go to page 4



For Advance Setup Only

3b. If you require an advance Network Setup, don't enable **DHCP** instead you can enter your own Gateways, DNS numbers, IP Address and Port number

4. Now continue the rest of your Setup



Example Only.

# CID SETUP (for Monitoring Station Communication)

1. Contact a Monitoring station to setup an IP-Monitoring account.
2. Fill in the boxes below with information provided by the Monitoring station.

Monitoring Information

Account Code (A) ✓ = **Must have information**

User Name (optional)      User Password (optional)

Monitor Name (IP Address) (C) ✓      Monitor Port # (B) ✓      CID Code (optional)

Alternative Monitor Name      Alt Monitor Port #      CID Code (optional)

IP Monitor Fail CID Code (optional)

Polling Interval (optional)

IP ALARM Protocol (tick one) ✓

CSV IP ALARM      PATRIOT LS-30      AAP ECID

3. Continuing from Network setup Click on CID Settings

4. Make sure Enable CID Reporting is Ticked

5. Start filling in all the monitoring station info:


A.  
B.  
C.

(putting any other info requested)

6. Now select the IP Alarm Protocol


7. Once all info is entered press the **TAB** key

8. Then click on **Save & Restart**



Example Only.

9. Power down the IP-Module and wire it up to the Alarm Systems dialler line-in and connecting it to the internet router.




# APP SETUP (For Personal Smartphone Monitoring & Control)

1. Continuing from Network setup  
Click on **Mobile APP**


2. Tick both **Enable Mobile APP**  
and **Push to APP**

3. *optional.* Under **Application Serial No** a new  
Serial number can be entered. Changing this  
will cancel old users from accessing to Elite  
System and receiving push notifications.

4. Click on **Save & Restart**



5. When the home page appears Write down the  
**MAC Addr** and **APP Serial** on the RUNNER Details label  
*Refresh your web browser if the home page doesn't come up*




MAC ADDRESS. **4C-78-97-00-0F-7A**

APP SERIAL NO. **1962942663**

6. Stick the Label in the System Operating Guide and hand  
it to the end user. They will require these two numbers to  
setup the App. Search **Elite Control** in the App store to  
download the App.

5. Power down the IP-Module and wire it up to  
the Alarm Systems dialler line-in and connecting it  
to the internet router.

*Note.* Any CID set alarm dialler can send App Push  
notifications, but only the RUNNER 4/8 and RUNNER  
8/16 can use the Apps control features.  
(requires ARR-14 Bus connection cable)



# ALARM SYSTEM SETUP FOR REPORTING

## The Alarm System must also be programmed for reporting

You will need to programmed in:

1. A telephone number (this can be anything from 1-999999999)
2. That telephone number must be set to Contact ID reporting format.
3. The dialler must be enabled.

If you are using an **RUNNER 4/8-8/16** here are the Programming Addresses:

1. **P 181 E 1 E** (put in a phone number 123) **E**
2. **P 182 E 1 E** turn option **1** ON and **E**
3. **P 175 E 1 E** turn option **1** ON only and **E**

## ALARM SETUP FOR REMOTE CONTROL (RUNNER 4/8-8/16 ONLY)

The RUNNER 4/8-8/16 has up to 8 outputs that can be controlled via the Elite Control App. Each output must be setup individually if you wish to control them remotely. These 3 steps below need to be done in Installer Program Mode of the RUNNER 4/8-8/16.

### 1. Output Options

The first thing you need to setup is giving permission for that output to be controlled by keypads. This is done at address 34. In Installer mode press **<PROGRAM> <34> <ENTER>** then choose the output **<1-8>** and **<ENTER>**, now turn ON option **<7>** and **<ENTER>**.

i.e. **P 34 E 4 E 7 E** (output 4 can is now allowed to be controlled).

↑ address  
↑ output number  
↑ option to be turned On

*Note: Outputs 1 & 2 are setup by default to be sirens and would not normally want to be controlled via the virtual terminal.*

### 2. Keypad to Output Control Mapping

The keypad number of the IP-Module (fixed to No.8) must now be assigned to the output/outputs you wish to control. This is done at address 83. In Installer mode press **<PROGRAM> <83> <ENTER>** then select the keypad number **<8>** and **<ENTER>**, now choose the output/s **<1-8>** and **<ENTER>**.

i.e. **P 83 E 8 E 4 E** (the App can now control output 4).

↑ address  
↑ keypad number of IP-Module  
↑ output number

### 3. Output Reset Times


The output reset time will normally already be set, according to the device it controls. Because of the delays involved in IP-Control, if an output has a reset time of less than 2 second you will not see a triggered response in the Virtual Terminal. In Installer Mode press **<PROGRAM> <40> <ENTER>** then the output you wish to change **<1-8>** and **<ENTER>** now put in the new reset time **<0-9999>** and **<ENTER>**.

i.e. **P 40 E 4 E 2 E** (output 4 reset time is now 2 seconds, recommend for garage door control).

↑ address  
↑ output number  
↑ new time in seconds

# OPERATING AND TROUBLE SHOOTING

## LED INDICATIONS



BLUE FAST FLASHING 4 flashes every second	Ready	Network detected
BLUE SLOW FLASHING 1 flash every second	Fault	No Network detected
GREEN STEADY	Dialling Out	The alarm panel connect to the Line-in terminals has Looped the line and is attempting to dial out.
BLUE STEADY	Monitoring Fail	Unable to connect to the Monitoring Station.
RED STEADY	APP Server Fail	The IP-Module has failed to connect to the network router and be assigned an IP address/gateway
RED FLASHING	ULD Operating	Remote Upload/Download software is accessing the Panel through the IP-Module
ALL FLASHING	DEFAULT	There is no programming saved in the module
LED 3 & 4 Alternating	Setup Error	Neither CID or Mobile APP reporting is enabled

## Getting Back into Program Mode with DHCP Enabled

Once you have Enabled DHCP and connected the IP-Module to the router a new IP Address will automatically be assigned. This can cause a problem when you try to get back into it's web page to change programming.

Follow these steps to get back into the web page:


1. Power down the IP-Module.
2. Connect the IP-Module directly to your PC/MAC (as shown in diagram 1)
3. Power up the IP-Module.

You will then be able to use the default IP address (192.168.1.100) to get into the setup web page.

## Resetting

Warning, performing a Reset will wipe all programming fields and return the IP-Module back to factory default. This includes returning it's IP address back to (192.168.1.100).


To reset simply press and hold the reset button until the LED turns Off. (about 5 second)



These 4 LED's will start flashing, when you press the reset button

## Optional Wiring.

By wiring as shown here the IP-MODULE can reboot the router, should there be a connection problem.



To utilise the Router Reboot feature, you will need to enable it through the IP-Modules web page.

Log into the IP-Module. Under **'Network'** there is a box labelled **'Relay Count'** (default 0 = OFF)

This number equals the number of reboot attempts the IP-Module will perform on the Router before giving up and waiting for the connection to automatically recover. (A couple of attempts is all you would normally need).

**'Router On Delay'** is the time in which the router should have come back online, before another reboot is attempted.

**Note: In the event of a power failure your alarm may not be able to report, due to 3rd Party hardware not being battery backed-up.**

## CROW ELECTRONIC ENGINEERING LTD.

12 Kineret St.  
 Airport City, 70100 Israel  
 Tel. +972 3 9726000  
 Fax. +972 3 9726001  
 support@crow.co.il  
 www.thecrowgroup.com

P/N 7103291 Rev A